





ORBITER CLOCKWORK ASSEMBLY MANUAL

We build space shuttles with gardening tools so anyone can have a space shuttle of their own.

HARDWARE



SOCHET HEAD CAP SCREW (SHCS)

Metric fastener with a cylindrical headand hex drive.


M3x8 Quantity 1



SOCHET HEAD CAP SCREW (SHCS)

Metric fastener with a cylindrical headand hex drive.

M3x10 Quantity 1



SOCHET HEAD CAP SCREW (SHCS)

Metric fastener with a cylindrical headand hex drive.

M3x20 Quantity 2



TAPERED HEAT-SET INSERTS FOR PLASTIC

The tapered shape makes it easier to guide these inserts into a hole during installation. Use a drill bit to create a straight hole, then taper the top half. Heat inserts with a soldering tip so that they melt the plastic when installed. As the plastic cools, it solidifies around the knurls and ridges on the insert for excellent resistance to both torque and pull-out.

M3 Brass Heat-Set Insert Quantity: 9

PTFE Tube

The PTFE tube is used between the Orbiter extruder and the Toolhead. Specific hot end lengths are listed below:



PTFE Tube Length 45mm

E3D V6 Hot end PTFE Tube Length ??mm (Not Tested Yet)

Slice Engineering Mosquito Hot end PTFE Tube Length ??mm (Not Tested Yet)



PRINTED PARTS



Clockwork_Adaptor_Front.stl



Clockwork_Adaptor_Back.stl



Chain_Anchor_SwitchWire.stl
Chain_Anchor_Voron_2.4.stl



[a]_Connector_Cover.stl





[a]_Filament_release_lever.stl

ASSEMBLY GUIDE


Assembly A. Heat-Set Inserts


Assembly B. Orbiter Clockwork Adapter






Assembly C. Connecter Cover and Chain Anchor







Screw into Plastic




Assembly D. Filament Quick Release Lever



* Depending on use this may need to be replaced with a Heat-Set Insert in future iterations.



*Screw in just enough to secure filament release lever, as it should be able to move freely.



Assembly E. Clockwork Adapter

